




iQ-Automator

User Manual

Version 2

October 29, 2021





CONTENT

1	PREFACE	4
1.1	Minimum requirements	4
1.2	Installation	4
1.3	Safety instructions	5
1.3.1	Danger	5
1.3.2	Warning	5
1.3.3	Intended use	5
2	INITIALIZE ROBOT	6
2.1	Set-up Robot Arm network	7
2.2	Check digital output mode	8
2.3	Enable remote control	9
2.4	Start Robot Arm	11
2.5	Mobile phone mounting	14
2.6	Tool Center Point (TCP)	15
3	SOFTWARE USAGE	16
3.1	First start	16
3.2	Initial import of configuration files	16
3.3	Set-up IP address of Robot Arm	16
3.4	Finding the home positions of the iQ-Bench and Robot Arm	17
3.5	Image acquisition from the mobile phone for extracting EXIF data	17
3.5.1	Image acquisition from mobile phone for auto-alignment	21
3.5.2	Mobile device settings and camera properties	22
3.6	Tool Center Point (TCP)	23
3.7	Training of Robot Arm and iQ-Bench (position recording)	23
3.7.1	Train the positions of the test devices	26
4	TASK ITEMS - CONTROL OF AUTOMATOR COMPONENTS	27
4.1	Illumination devices	28
4.2	Motion control items	28
4.3	Script	28




5	WORKFLOW EDITOR.....	28
5.1	Task Settings	28
5.1.1	Illumination.....	29
5.1.2	iQ-Trigger.....	29
5.1.3	iQ-Trigger release time	30
5.1.4	Robot Arm.....	30
5.1.5	Axes.....	31
6	THE SCRIPT TASK.....	31
6.1	Example 1: workflow with iQ-Analyzer:.....	32
6.2	Example 2: start-up mobile device.....	32
6.2.1	Workflows	33
6.3	Process workflow	34
7	3RD PARTY COMPONENTS	34



1 PREFACE

The iQ-Automator software provides a substantial time saver for testing your mobile phones while eliminating human error and creating more precise and accurate testing. The software can control the iQ-Automator Solution and create a testing sequence.



iQ-Automator GUI

1.1 Minimum requirements

- Windows 10 32bit
- USB 2.0 or higher
- Ethernet connector (for robot arm)

1.2 Installation

The iQ-Automator control software is available in 32bit. During installation, the drivers and additional software will be installed. Along with the iQ-Automator software, the installation includes the following:

- Microsoft Visual C++ Redistributable Package
- Hardware drivers

1.3 Safety instructions

1.3.1 Danger

- Make sure to install the robot and all electrical equipment according to the specifications.



1.3.2 Warning

- Ensure the robot arm and tools are correctly and securely bolted in place.
- Confirm that the robot arm has ample space to operate freely.
- As defined in the risk assessment, verify that safety measures and the robot safety configuration parameters have been set up to protect programmers, operators, and bystanders.
- Do not wear loose clothing or jewelry when working with the robot. Make sure long hair is tied back when working with the robot.
- Never use the robot if it is damaged.
- If the software prompts a fatal error, immediately activate the emergency stop, write down the conditions that led to the mistake, find the corresponding error codes on the log screen, and contact Image Engineering.
- Do not connect any safety equipment to standard inputs/outputs. Only use safety-related interfaces.
- Use the correct installation settings (e.g., robot mounting angle, weight in TCP, TCP offset, and safety configuration). Save and load the installation file along with the program.
- Use the free drive function (impedance/back-drive) only in installations where the risk assessment allows it. Tools and obstacles should not have sharp edges or pinch points. Ensure all personnel keeps their heads and faces outside the robot's reach.
- Be aware of the movement of the robot when using the teach pendant.
- Do not enter the safety range of the robot or touch the robot when the system is in operation.
- Collisions can release high portions of kinetic energy, significantly higher at high speeds and with large payloads.
- Combining different machines might increase hazards or create new dangers. Always do an overall risk assessment for the complete installation. Always choose the highest level when other safety and emergency stop performance levels are needed. Be sure to read and understand the manuals of all the equipment used in the installation.
- Never modify the robot, as a modification might create unforeseen hazards for the integrator. All authorized reassembling shall be done according to the newest version of all relevant service manuals.



1.3.3 Intended use

The intent of the joint operation is only for non-hazardous applications. The complete application, including tools, workpieces, obstacles, and other machines, is without any significant hazards according to the risk assessment of the specific application.


Any use or application deviating from the intended use is deemed to be impermissible misuse. This misuse includes, but is not limited to:

- Use in potentially explosive environments
- Use in medical and life-critical applications
- Use before performing a risk assessment

- Use where the rated performance levels are insufficient
- Use where the reaction times of the safety functions are insufficient
- Use as a climbing aid
- Operation outside the permissible operating parameters

2 INITIALIZE ROBOT

Please familiarize yourself with the robot arm (UR3e) user manual. This chapter only describes the steps necessary to work with the iQ-Automator software. When using the robot arm with the iQ-Automator software, it must be initialized with the connected controller tablet.




Enter the current weight (payload) mounted on the tool plate (these weights are stated directly below).

Weight of the iQ-Mobilemount plus the iQ-Trigger-T: ~1080 g



2.1 Set-up Robot Arm network



An Ethernet connection is not necessary for the basic robot functions and is disabled by default. To work with the iQ-Automator, please enable **DHCP** or set a **static IP address**. In both cases, the IP address must be entered later in the software (see chapter **Error! Reference source not found.**).




2.2 Check digital output mode

The screenshot shows the 'I/O Interface Control' settings window. The 'General' tab is active, and the 'I/O Setup' section is expanded. The 'Controlled by' dropdown is set to 'User'. The 'Analog Inputs - Communication Interface' section has 'Analog Inputs' selected, with 'analog_in[2]' and 'analog_in[3]' both set to 'Voltage'. The 'Communication Interface' section is unselected. The 'Tool I/O' section is expanded, showing 'Baud Rate' at 115200, 'Parity' at None, 'Stop Bits' at One, 'RX Idle Chars' at 1.5, and 'TX Idle Chars' at 3.5. The 'Digital Output Mode' section is highlighted with a red box. It contains the text 'Tool Digital Output mode is defined based on the tool attached', 'Tool Output Voltage' set to 0, and a warning icon with the text 'Setting the tool voltage to 24V may damage attached equipment if it is only configured to 12V'. Below this, 'Dual Pin Power' is unselected, and 'Standard Output' is selected. 'Digital Output 0' and 'Digital Output 1' are both set to 'Sinking (NPN)'. The bottom status bar shows 'Normal' mode, 'Speed' at 100%, and 'Simulation' disabled.

Please check that the “Tool Output Voltage” is set to 0.



2.3 Enable remote control



Please be aware that if you enable “Remote Control,” some control panel functionality is disabled.



PROGRAM <unnamed>
INSTALLATION default

Run Program Installation Move I/O Log

New... Open... Save...

Local 5 F 7 1

Program <unnamed>

Load Program

Status
Stopped

Variables

No Variables

Remote Control

Robot Age

Days Hours Minutes Seconds
1 09 15 35

Show Waypoints

Power off Speed 100%

Simulation

Once enabled, you can switch between local and remote control with the “Local” button on the top right corner of the interface.



2.4 Start Robot Arm


The screenshot shows the 'Initialize' screen of the robot control software. The 'Robot Status' section displays a progress bar with five stages: Power OFF (red circle), Booting (grey circle), Robot Idle (grey circle), Brake Release (grey circle), and Robot Operational (grey circle). Below the status bar is a control panel with a green 'ON' button and a grey 'OFF' button. A message below the buttons says 'Confirm if Installation and Payload are correct and press the ON button to start.' The 'Payload' section has a warning icon and text: 'Active Payload is used to temporarily overwrite the Installation Payload.' It shows 'Active Payload' and 'Installation Payload' both set to '1.50 kg'. The 'Robot' section has the text 'Power ON the robot first'. At the bottom, there is a 'Power off' button, a 'Speed' slider at 100%, and a 'Simulation' toggle switch.

You need to weigh the device under test during this step and input the value into “Active Payload.” Please note that the weight of the device under test does not need to be exact. We recommend that you take the average of a few different mobile phones and use that value as your “Active Payload,” so you don’t need to measure the exact weight of every mobile phone.




Attention! Please add the weight of your device under test to the weight of the Installation Payload. Enter the sum into “Active Payload.” For example, Installation Payload is 1.5 kg, and the DUT weight is 200 g. The value you need to enter into the “Active Payload” space is 1.7 kg.

Once that is complete, you can click the “on” button.





Once you click “On” (see the previous image), the button will change to “Start,” and you can click it once the program has completed booting and the robot arm is in normal mode.



These steps are all necessary for starting the program. Once activated, please check to ensure everything is actively working (all green circles with checks). For all other actions, please refer to the robot arm manual.

2.5 Mobile phone mounting

Mount the mobile phone on the iQ-Mobilemount, as shown in the images. Align the lens to the center of the tool plate.



Attach the iQ-Trigger-T to the phone using the rubber band. Place the active area of the iQ-Trigger-T over the release button of the native camera application. Connect the phone with the USB cable to the USB extension cable.



2.6 Tool Center Point (TCP)

The tool center point is defined as a target position in space to the coordinate origin of the robot arm's mounting plate. In the context of the iQ-Automator, the TCP needs to be set to the lens of the mounted phone.

If the phone is correctly aligned with the lens perpendicular to the mounting plate's center, then only the vertical distance of the lens to the mounting plate needs to be measured (z-coordinate). Enter the value into the software (see chapter **Error! Reference source not found.**).



Align the measurement tool with the lens and then record the vertical distance.

3 SOFTWARE USAGE

Along with the different Image Engineering hardware components, the iQ-Automator software provides an efficient and time-effective option to automatically test and give feedback on the image quality of a digital camera. The software enables users to create workflows involving various connected Image Engineering devices. The critical elements of this solution are the iQ-Bench and the robot arm with six degrees of freedom. The combination of translation and rotation movement and the ability to control motor-driven devices, iQ-LED-powered devices, and iQ-Standardlight devices provides the basis of extraordinarily versatile software.

Logging Functionality:

The software writes a log.txt file to C:/Users/<user>/AppData/Roaming/Image Engineering/iQ-Automator. A lot of information for debugging purposes is saved here. If an error appears or a crash happens, copy this file to another directory and send it directly to Image Engineering support. This process helps us to detect errors and improve the software.

3.1 First start

Enter the license key when starting the software for the first time. You can find the key in a text file on the USB stick.


3.2 Initial import of configuration files

- In the iQ-Automator **File** menu, choose the **Load configuration file** and select the provided configuration files for all moving parts, the iQ-Bench, the robot arm, and the iQ-Teststand. Normally, the file that needs to be loaded is labeled IE_Drive_Configuration.xml, and it configures all dependent moving devices.
- Choose **File> Import hardware setup** and select the provided XML files in the folder (select Hardware.xml and all others) to load your test chart setup. Give this setup a name in the dialog. **The XML files need to be configured first; see the iQ-Automator support document instructions.**
- If you have existing illuminant files for iQ-LED devices, choose **file> Import illuminants** and select the illuminant files. The illuminants are available in the software at each start-up.

3.3 Set-up IP address of Robot Arm


Go to **Options > Set robot arm IP...** to enter the IP address of the robot arm. Once confirmed, it should establish the connection to the robot arm.





3.4 Finding the home positions of the iQ-Bench and Robot Arm

Click the **Calibrate** button to perform the homing procedure for the robot arm to find its default position on the iQ-Bench. The home switch on the front side defines the iQ-Bench's default position of the iQ-Bench. The robot arm will simultaneously move its elements to designated (home) positions.




The homing switch is released by the metal plate mounted at the front side of the carriage


3.5 Image acquisition from the mobile phone for extracting EXIF data

You must first meet some prerequisites for the auto-alignment procedure and the connection to the mobile phone.

a) Before using the software, ensure that the mobile phone is set to file or image transfer mode when connected to a PC with the USB cable:




b) Verify the successful connection by opening the phone in Windows Explorer:



c) In the "DCIM" directory (or a sub-directory), the images from the camera must be visible.


d) Prepare the camera application.

Set the camera resolution in the native camera application to the highest setting, in either the 4:3 or 16:9 format. This step is vital for the calculation of the pixel pitch of the camera's sensor. For example:




Take a photo with the native camera application. The content does not matter; it is only used for extracting EXIF data.

If the camera application is switched to the front-facing camera, there may be an option for flipping the image when it is saved. Please set it to a non-flipping state. For example:



e) Connect the phone

The phone name appears in the Options/Mobile devices menu when a mobile phone is connected to the PC and the software is running. The phone name appears in the Options/Mobile devices menu. For example:



The software needs some information from the EXIF data of an image captured with the phone. When connecting a phone of a dedicated model to the software for the first time, you should scan the device for such an image. After clicking "Start scanning device," the software chooses the picture from all the images on the phone with the latest modification date. The search can be restricted to the DCIM directory ("Use DCIM directory"), where the native camera application usually stores images.

This image is copied to `C:/Users/<user>/AppData/Roaming/Image Engineering/iQ-Automator`. The software extracts two values (crop ((or scale)) factor and the focal length) from the EXIF meta information of the image file, which is required for the auto-alignment procedure. The focal length is read directly from the meta information, while the pixel pitch is calculated from other values. With these values and the positions of the red markers in the images taken during the alignment procedure, the software can calculate the correct alignment for the iQ-Bench and the robot arm.

Let's suppose that the EXIF data lacks such information, which means that at least one value is invalid. In that case, the user can enter the correct values for both focal length and pixel pitch from a datasheet or other sources of technical data.

Once two correct values are available, they are stored permanently and used again if a phone of the same model type is connected.



3.5.1 Image acquisition from mobile phone for auto-alignment

An auto-alignment for the target chart can be performed if the following issues are fulfilled:

- The XML configuration for the chart has an *AutoAlignment* entry set to true with all necessary entries. The *TargetDimensions* entries have correct values for the red markers and the target size (see support document).
- The phone is successfully connected (see chapter [2](#)).
- The mobile phone is mounted correctly on the iQ-Mobilemount (see chapter [2.5](#)).
- The iQ-Trigger is mounted on the release button of the phone's native camera application.
- The Automator was taught the initial position where the first image will be taken. All four red markers must be seen on the monitor, and the robot arm should be arranged so that the viewing angle of the chart is minimized. This setup implies that the camera is aligned perpendicularly to the center of the target (e.g., the chart center).
- The tool center point for the mobile phone lens has been measured and entered in the corresponding fields of the dialog mentioned above.
- A minimal workflow with the target motion control element was created.
- Calibrate button was clicked, and the iQ-Bench and robot arm moved to their home positions.

Now, a successful alignment can be performed when the workflow is started. Check the performance by adding an iQ-Trigger task right after the motion control task. The iQ-Trigger rereleases the camera after alignment has finished, and the resulting image is saved to the disk. Verify that the target center (e.g., the central marker of a chart) is close to the image's center. During the alignment procedure, four images are taken, in which the four red markers are detected. Those images are also saved to C:/Users/<user>/AppData/Roaming/Image Engineering/iQ-Automator, but always with the same name, "temp.jpg," and only temporarily. After successfully detecting markers in the image, the temp image is deleted.

3.5.2 Mobile device settings and camera properties

The connected mobile device is listed under Options > Mobile devices. When selected, a dialog with mobile phone settings appears. Additional information must be retrieved (one-time) from the image EXIF data from the mobile phone to execute the auto-alignment process correctly. The numbers in the following paragraphs refer to the numbers in the image.



1. The manufacturer and the phone model name are displayed here.
2. An image file must be available on the phone to obtain the correct EXIF data. The image must be in the highest resolution and captured in 4:3 or 16:9 mode. Start the native camera application, set the appropriate options, and take a sample image. When you click the "Start scanning device" button, the directory tree of the mobile phone is scanned for image files, and the one with the latest modification date is chosen for EXIF information retrieval. Depending on the number of images on the phone, this search may take some time. Click the button to start scanning after checking the settings described in the following two paragraphs.
3. Usually, the native camera application stores its images in a directory called "DCIM." If the option "Use DCIM directory" is selected, the search will be restricted (default setting).
4. Some mobile phones simultaneously store a thumbnail image next to the original one. This issue may lead to EXIF data accessing an invalid thumbnail image. In this case, a minimum value for the file size of the images is specified here. Images below this size are skipped during scanning. The default value is 100 KB. After successful scanning, four distinct values from the EXIF data of the most recent image are displayed. Three values are directly extracted, and one is indirectly calculated from the others.
5. The focal length of the lens is in mm. This value can be edited.
6. As parameters, pixel pitch is calculated indirectly from the image size and the crop factor. This value can be edited. **If you feel that the focal length and pixel pitch values are potentially imprecise, you can enter well-known values here.** Both values are saved permanently to the disc and are reloaded whenever a mobile phone of the same model type is connected again. This feature avoids the scanning procedure and restores the current values.
7. The equivalent focal length of 35 mm is displayed here for information purposes.

8. The crop (or scale) factor is the ratio between the physical focal length of the lens and the assumed equivalent for a 35 mm sensor (film) size. It is used for the calculation of the pixel pitch.
9. Hold the mouse cursor over the info button to display the EXIF data's image. This feature will ensure that the EXIF information was not extracted from the wrong image.
10. The release time for the iQ-Trigger-T can be edited here. The default value of 300 milliseconds is sufficient for most mobile phones. In rare cases, a smaller value of 200 ms is advisable due to the possibility that the camera application may enter the burst mode with 300 ms and capture a series of images instead of one.

Finally, click *OK* to save all settings or *Cancel* to discard all settings.

3.6 Tool Center Point (TCP)

Go to **Train robot arm > TCP setting** in the **Options** menu. Enter the measured vertical distance (z-value) for the TCP (chapter [2.6](#)):

The screenshot shows two panels from a software interface. The top panel, titled 'Train target position', contains a sequence of buttons: 'Release drives', 'Move bench and robot arm to target position', 'Lock drives', and 'Save position'. Below these buttons is a table with two rows of data:

Target	Base	Shoulder	Elbow	Wrist 1	Wrist 2	Wrist 3	Bench
Chart	189.79°	-113.1°	-95.47°	-61.81°	270.53°	79.15°	1.14m
lightSTUDIO	112.25°	120.84°	48.63°	100.58°	273.82°	72.38°	0.15m

The bottom panel, titled 'Tool Center Point', shows a dropdown menu for 'Tool center point:' set to 'Huawei Mate 20 Pro'. Below this are input fields for X, Y, Z, RX, RY, and RZ. The Z field is set to '90 mm'. There are also '+' and '-' buttons next to the dropdown and a 'Save TCP' button. A 'Done' button is at the bottom.

3.7 Training of Robot Arm and iQ-Bench (position recording)



For each mobile device, the robot arm's initial positions and iQ-Bench need to be recorded and stored in the software. When "Train robot arm" is selected from the menu, the iQ-Bench and the robot arm can be released by clicking the "Release drives" button (this will allow you to adjust the robot arm manually). Please ensure that someone is holding the robot arm at this moment, so it does not collapse. The person holding the arm can now freely move the arm and adjust the base plate on the bench to show all four red markers on the mobile phone screen. The position should be chosen with respect to the following conditions:

- Only the four red markers that belong to the chart are visible in the display. If the iQ-Automator in your setup includes an iQ-Chartmount with other charts, please ensure that no other red marker is visible. In addition, other red artifacts with similar size and roundness may impact the auto-alignment procedure.





- Please ensure that when freely moving the arm, it is moved in the correct position. Review the following images for the proper movement.

Examples of incorrect positioning, which leads to failure of alignment procedure:



Examples of acceptable positioning:




- After this coarse alignment, click "Lock drives" and "Save position."
- Now a new task workflow for this mobile phone needs to be created.

3.7.1 Train the positions of the test devices

Select **Train robot arm > TCP setting** in the **Options** menu. For each mobile phone type, each test chart must provide an initial position of the bench and robot arm. This position is either the starting position for the auto-alignment procedure or the final position in the case of manual alignment. The use case for each destination chart is defined in the XML files for the hardware setup. The auto-alignment requires four red markers to be mounted around the destination chart and corresponding entries in the XML configuration (see support document). Usually, the complete setup of devices, test charts, XML configurations, and red markers is performed during the commissioning of the iQ-Automator. For subsequent amendments, please get in touch with the Image Engineering support team.

The following procedure should be performed by two people, one who operates the software and the other who moves the bench and robot arm to the initial position. Although the robot controller can hold its joints in place when the brakes are released, a person should hold the robot arm when clicking the **Release drives** button to ensure the arm doesn't collapse.



- Click the **Release drives** button to unlock the iQ-Bench and the robot arm. The second person can now move the carriage of the iQ-Bench and the robot arm to the desired position. The monitor of the mobile phone should display the target chart so that all four red markers are visible and not too far from the frame borders:




During movement, the positions of all movable parts are updated.

- Click the **Lock drives** button.
- To save the current position, click **Save position**.
- Click **Done** to leave the setup dialog.

All workflows created with auto-alignment configurations now use the recorded position as the initial position.

4 TASK ITEMS - CONTROL OF AUTOMATOR COMPONENTS



The available items are separated into three different sections including:

- Devices for illumination, such as the iQ-Flatlights, and devices for image capturing, e.g., the iQ-Trigger.
- Motion control items for the main bench, the robot arm, and devices such as the moving targets of a lightSTUDIO-M.
- Scripting for the control of the mobile phone with the ADB tool or an evaluation with the iQ-Analyzer command-line tool.

A workflow may consist of different items from these sections.

4.1 Illumination devices

This section connects each illumination device that is based on iQ-LED or iQ-Standardlight technology. The iQ-Trigger control can also be connected here.

4.2 Motion control items

Blue items: represent the moving parts of the iQ-Bench and the robot arm toward a target chart. These items are configured with XML files and perform an **auto-alignment** with an initially trained position.


Green items: represent the movements of other connected moving parts. These items are configured with XML files and perform a manual alignment with an **initially trained** position.

Orange items: represent individual movements of the robot arm or any other moving device with no specific target. These movements are configured in the workflow editor.


4.3 Script

The script tile enables you to write or call batch scripts.

5 WORKFLOW EDITOR




Drag and drop the desired items to the track and create a workflow with the different task items. All tasks in a workflow are executed subsequently. The maximum number of slots for tasks in the workflow track can be changed.



5.1 Task settings

The blue and green motion task items have no specific settings since they are configured in the XML files. All other task items can be edited by simply double-clicking on them.


5.1.1 Illumination



Illumination settings

The illumination settings panel offers control options for iQ-Standardlight devices and all types of iQ-LED devices. Illuminant files are available for a connected iQ-LED illumination device, such as iQ-Flatlights, and those illuminants can be selected here. See chapter **Error! Reference source not found.** for importing illuminant files. iQ-LED illumination files must be created using the iQ-LED software. After that, select the illumination device and a corresponding illuminant. For example, multiple devices, such as two iQ-Flatlights with the same illuminant for test chart illumination, can be chosen.

5.1.2 iQ-Trigger



The iQ-Trigger task item captures the final image after successful alignment (automatic or manual). The trigger time sets the release time of the iQ-Trigger-T. The default value of 0.3s applies to most mobile devices. In rare

cases, this release time may provoke the burst mode of the camera application. A value of 0.2s should then be set for this device.


Delay to the next task defines the time in seconds until the next task item is executed. This option can be helpful if the camera needs some time to focus after the trigger is released.

5.1.3 iQ-Trigger release time

If an iQ-Trigger task is dragged to the task timeline, the default release time for the iQ-trigger is set to 0.2s. During a few use cases, it was discovered that this value might be too short for some phones, leading to random dropouts of camera releases. Try to increase the release time in 0.1s steps until the iQ-trigger reliably releases the camera.


Contrary to this, an extended-release time may start the camera exposure in burst mode. For some phones, a release time of 0.3s or 0.4s may be too long and lets the camera take a series of images.

5.1.4 Robot Arm



The robot arm can be moved to any position within its tool workspace. Please be aware that combinations of the six parameters (for the six joints) are outside this workspace. Using the UR controller in advance is recommended to test possible destinations. Read the manual of your robot arm for further information about the workspace. You may also release the brakes of the robot arm to move it to a target position and then save these values here.

5.1.5 Axes




Each axis connected to the PC can be moved to any desired position. In general, it is the main iQ-Bench with the robot arm, but the moveable parts of a lightSTUDIO-M may also be used here when it is connected. A looping function is also included.

6 THE SCRIPT TASK

The script task console uses the Windows command prompt (cmd.exe) and its syntax. A temporary batch file *.bat is created from your input in the script task console and executed as a task. This process enables the iQ-Automator to launch applications such as the iQ-Analyzer for image evaluation. You also have the option to run your python scripts.

If the checkbox "**Wait for finished**" is checked, the iQ-Automator will proceed with the next task after the executed batch file has finished. Otherwise, the process will be done in the background while other tasks are performed.

6.1 Example 1: Workflow with iQ-Analyzer:



When processing images with a TE42 test chart and the iQ-Analyzer, please add the following lines to the scripting text field:

For versions < 6.2

```
cd /d C:\<Path to iQ-Analyzer>\iQ-Analyzer V6.1.9\iqa6cmd.exe "%IQ_IMAGE_PATH%*.jpg" "C:\<Path to iQ-Analyzer>\iQ-Analyzer V6.1.9\Data\TE42_V2_Data.42" 42
```

Analyzer versions >= 6.2

In the iQ-Automator application %IQ_IMAGE_PATH%, you will find the reserved variable containing the path to the folder where the previously captured image is located.

For further information on using the iQ-Analyzer command-line tool, please read the iQ-Analyzer manual.

The iQ-Analyzer should not be installed in C:\Program Files\ to use the command-line application in the iQ-Automator software. Instead, install the iQ-Analyzer to C:\Image Engineering\iQ-Analyzer.

6.2 Example 2: start-up mobile device

Most mobile phones shut down the camera application and enter sleep mode if not actively used, disrupting your test proceedings. As a result, it is crucial to ensure the phone is awake and unlocked by starting the camera application manually. Creating a script to automate this procedure through the ADB (Android Debug Bridge) is also possible. Download the ADB tool and install it to an appropriate destination on your PC (e.g., C:\Program Files\ADB). With the **ADB shell** command, some UI input events of the phone can be simulated. The **input** command-line tool is used for this purpose.

Here is a sample for a phone that has no password protection:

- 1) Generates a keypress event for powering up
- 2) Generates a swipe gesture from coordinates 500,1500 to 500, 500 (swipe up)
- 3) Generates a keypress event for starting the camera application


```
C:\Program Files\ADB\adb.exe shell input keyevent 26
```

```
timeout 2
```


```
C:\Program Files\ADB\adb.exe shell input touchscreen swipe 500 1500 500 500
```

```
timeout 2
```

```
C:\Program Files\ADB\adb.exe shell "input keyevent = CAMERA"
```



6.2.1 Workflows




After all desired tasks are configured, save the tasks to a workflow item. Click Create workflow, enter a self-explanatory name, and set an icon or a color (optional). Be aware that the workflow depends on the trained position for the current device and the camera settings, so we recommend adding the mobile phone type and

some other information to the name. An example:


<Manufacturer> <Phone Name> <TE42> <4:3>

After confirmation, the workflow editor is cleared, and a workflow tile is added to the workflow collection.



Double-click the desired tile to change an existing workflow item. A new window will appear with all task items. Click **Copy to workflow editor**. The task items can now be edited, and a new workflow can be created again. Choose a different name for the workflow or delete the old workflow item.

6.3 Process workflow



To begin, drag and drop a workflow item to the **Workflows sequence** and click the **Start** button.

7 3RD PARTY COMPONENTS

The iQ-Automator software uses open-source software:

libusb (www.libusb.org) is licensed under the GNU Lesser General Public License version 2.1 or later (www.gnu.org/licenses/old-licenses/lgpl-2.1.html).



The [Qt framework](http://www.qt.io) (www.qt.io) is licensed under the commercial Qt license.

OpenCV (<https://opencv.org>)

License Agreement

For Open-Source Computer Vision Library

(3-clause BSD License)

Redistribution and use in source and binary forms, with or without modification, are permitted, provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions, and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the names of the copyright holders nor the names of the contributors may be used to endorse or promote products derived from this software without specific prior written permission.

This software is provided by the copyright holders and contributors "as is," and any express or implied warranties, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are disclaimed. In no event shall copyright holders or contributors be liable for any direct, indirect, incidental, special, exemplary, or consequential damages (including, but not limited to, procurement of substitute goods or services; loss of use, data, or profits; or business interruption) however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the use of this software, even if advised of the possibility of such damage.

Exiftool (<https://www.sno.phy.queensu.ca/~phil/exiftool/>) is free software licensed under the GNU Lesser General Public License version 3.0 or later (www.gnu.org/licenses/lgpl-3.0).